

Linux RHEL On HighPoint NVMe RAID Controller Installation Guide

V1.03-Nov 22, 2023

Copyright © 2023 HighPoint Technologies, Inc.

All rights reserved.

Table of Contents

1 Overview	1
2 Installing Linux RHEL on NVMe controller	2
Step 1 Prepare Your Hardware for Installation	2
Step 2 Check System EFI Settings	2
Step 3 Flash UEFI ROM to NVMe controller	4
Step 4 Create Array	5
Step 5 Prepare the Driver Diskette	
Step 6 Install RHEL	6
3 Monitoring the Driver	11
4 Installing RAID Management Software	11
5 Troubleshooting	11
6 Rebuilding Driver Module for System Update	
7 Appendix A	

1 Overview

The purpose of this document is to provide clear instructions on how to install Linux RHEL to an SSD or RAID array hosted by HighPoint NVMe controllers.

The following is a list of NVMe controllers and system.

Supported System	RHEL7.9
	RHEL8.3
	RHEL8.5
	RHEL8.6
	RHEL8.7
Supported Controller	SSD7202
	SSD7105
	SSD7505
	SSD7502
	SSD7540
	SSD7580A
	SSD7580B
	SSD7580C
	RocketAIC 7505HW Series
	RocketAIC 7540HW Series
	RocketAIC 7749EW Series
	RocketAIC 7502HW Series
	RocketAIC 7105HW Series

2 Installing Linux RHEL on NVMe controller

If you would like to install Linux RHEL onto drives attached to the NVMe controller, please perform the following operations:

Step 1 Prepare Your Hardware for Installation

After you attach your NVMe SSD to the NVMe controller, you can use **EFI Utility** to configure your NVMe SSDs into RAID arrays, or just use them as single disks.

Before installation, you must remove all the NVMe SSD, which are not physically attached to NVMe controller, from your system.

Note

NVMe controller only support EFI boot. If you have other SCSI adapters installed, you must make sure the NVMe controller EFI will be loaded firstly. If not, try to move it to another PCI slot. Otherwise, you may be unable to boot up your system.

Step 2 Check System EFI Settings

In your system EFI SETUP menu, change **Boot Sequence** in such a way that the system will first boot from **EFI** CDROM or **EFI** a Bootable USB drive; after you finish installation, set the NVMe controller as the first boot device to boot up the system. Refer to your motherboard EFI manual to see how to configure the boot sequence.


- 1. Set UEFI setting with SuperMicro X11DPi-NT motherboard as an example.
 - a. "Advanced->PCIe/PCI/PnP Configuration->CPUSlot PCI-E OPROM" to "EFI". Suppose NVMe controller is connected to motherboard CPU1 Slot 2 PCI-E X16, then you should set "CPU1 Slot 2 PCI-E X16 OPROM" to "EFI";




b. Disable "Secure Boot", set "Attempt Secure Boot" to "Disabled".




- 2. Configuring the UEFI settings (using an ASUS PRIME X299 -DELUXE motherboard as an example):
 - a. Set "Boot from Storage Devices" to "UEFI driver first";



b. And "Boot Device Control" to "UEFI Only" or "UEFI and Legacy OPROM";



c. Set "OS Type" to "Other OS".




Step 3 Flash UEFI ROM to NVMe controller

Example SSD7505:

Note: Make sure your USB flash partition format is FAT32.

For other products, please refer to: Update UEFI ROM

- a. Unzip SSD7505 UEFI package to the root dir(/) of a USB flash drive, and connect the USB flash drive to the motherboard;
- b. Boot from the UEFI USB flash and enter the UEFI environment;



c. Use the command "go.nsh" to flash UEFI ROM to the SSD7505 and reboot the system.

```
FS1:\> go.nsh
FS1:\> load.efi 7505uefi.rom
Load Utility for Flash EPROM v1.1.0
  (built at Jan 5 2021 13:30:42)

Found adapter 0x75051103 at PCI 33:0:0
Flash size 0x10000, File size 0xee00
Offset address 0x20000
EPROM Vendor: WINBOND W25X40BV
Erasing ....Suceeded
Flashing ...

Flashing Success (total retry 0)

Verifing ...

Passed !
FS1:\> _
```

d. Use the "exit" command to exit the utility.

Step 4 Create Array

Note: RocketAIC series NVMe drives are already pre-configured with RAID0. You can skip this step. If you want to use another type of RAID array for a Boot-RAID configuration, you can refer to the following steps.

- a. Attach NVMe SSDs to NVMe controller.
- b. Boot, enter the motherboard's Boot List and select start from UEFI USB flash.

```
Boot Override

UEFI: USB, Partition 1

(B97/D0/F0) UEFI PXE: IPv4 Intel(R) I350 Gigabit Network

Connection(MAC:3cecef40a1dc)
```

c. Use the command "ArrayCreate.efi" to enter the Utility:

d. Use the command "create RAID0".

This will create a RAID0 array using all of the NVMe SSDs, and the maximum available capacity.

- e. Use the "exit" command to exit the utility.
- f. For additional command lines, refer to Appendix A.

Step 5 Prepare the Driver Diskette

Extract **HighPoint_NVMe_RHELxx.xx.x_x86_64_vx.xx.xx_xx_xx_xx_xx_xx.tar.gz** to the top(/) directory of a USB flash drive. It will look like:

```
[root@localhost home]# tar zxvf HighPoint_NVMe_rhel8.7_x86_64_v1.5.1_23_04_18.tar.gz
hptdd/
hptdd/rhdd
hptdd/pcitable
hptdd/pci.ids
hptdd/modules.pcimap
hptdd/modules.setup.sh
hptdd/modules.cgz
hptdd/modules.cgz
hptdd/modules.alias
hptdd/modinfo
hptdd/modinfo
hptdd/install.sh
hptdd/do-persistent-storage-hptblock.rules
hptdd/rhel-install-step1.sh
hptdd/rhel-install-step2.sh
hptdd/readme.txt
```

Step 6 Install RHEL

Example: RHEL8.7

- a. Before starting the installation procedure, verify the status of your network environment. To ensure Ubuntu is successfully installed to the RAID array, we recommend that the system is disconnected from the internet and any local network.
- b. Insert the USB flash drive into the target system.
- c. Boot the system using a bootable USB drive.
- d. When the Installation screen appears, press 'e' to edit boot command line option.

```
Install Red Hat Enterprise Linux 8.7
Test this media & install Red Hat Enterprise Linux 8.7
Troubleshooting -->
```


On the edit command window, move the cursor to the end of line "linuxefi /images / pxeboot...", and append "modprobe.blacklist=nvme" (do not include the quotation marks).

```
setparams 'Install Red Hat Enterprise Linux 8.7'

linuxefi /images/pxeboot/vmlinuz inst.stage2=hd:LABEL=RHEL-8-7-0-BaseOS-x86_64 quiet modpr\
bbe.blacklist=nvme_
initrdefi /images/pxeboot/initrd.img
```

Press CTRL+X or F10 to start the system.

e. When the following window appears during the installation process,



Press Ctrl+ALT+F2 to switch to the shell on console and press Enter to activate this console.

```
Red Hat Enterprise Linux 8.7 (Ootpa)
Kernel 4.18.0-425.3.1.el8.x86_64 on an x86_64

[anaconda root@localhost /]# _
```

Next, execute the following commands:

mkdir /hptdd ← Create mount point for USB flash drive

mount /dev/sda1 /hptdd/ ← Mount the USB flash drive to /hptdd

cp -a /hptdd/hptdd /tmp/ ← Copy driver installation file to system

temporary directory

umount /dev/sda1 ← Unmount the USB flash drive

```
[anaconda root@localhost /]# mkdir /hptdd
[anaconda root@localhost /]# mount /dev/sda1 /hptdd/
[anaconda root@localhost /]# cp -a /hptdd/hptdd/ /tmp/
[anaconda root@localhost /]# umount /dev/sda1
```


When the USB flash drive is unmounted, please unplug the USB flash drive from the system. Next, execute the following commands to install driver for Linux RHEL.

sh /tmp/hptdd/RHEL-install-step1.sh ← Load NVMe controller driver.

```
[anaconda root@localhost /]# sh /tmp/hptdd/rhel-install-step1.sh
Driver Installation
Driver installation step 1 completed.
[anaconda root@localhost /]# restart-anaconda
```

f. Then press "ALT+F6" to switch back to installation screen and Choose language.

g. When the following window appears during the installation process,



1) Set Root Password



2) Set Software Selection and choose Server with GUI


Development Tools

0	Server with GUI
	An integrated, easy-to-manage server with a graphical interface.
0	Server
	An integrated, easy-to-manage server.
0	Minimal Install Basic functionality.
0	Workstation
	Workstation is a user-friendly desktop system for laptops and PCs.
0	Custom Operating System
	Basic building block for a custom RHEL system.
0	Virtualization Host Minimal virtualization host.
	Legacy UNIX Compatibility Compatibility programs for migration from or working with legacy UNIX environments.
	Container Management Tools for managing Linux containers
V	Development Tools
	A basic development environment.
	.NET Core Development
	Tools to develop .NET and .NET Core applications
	Graphical Administration Tools Graphical system administration tools for managing many aspects of a system.
	Headless Management
_	Tools for managing the system without an attached graphical console.
	MANUAL PROJECT OF THE


3) Select Installation Destination and click "refresh", but if you didn't find this option, you can press Ctrl+ALT+F2 to the shell and type # restart-anaconda



- 4) Then choose your own disk and begin installation.
- h. If the following information is displayed during the installation, select "Yes".



i. When the screen shows that "Complete!".



press Ctrl+ALT+F2 to the shell and type the following commands:

- # cp -r /tmp/hptdd /mnt/sysimage/tmp/hptdd
- ← Copy the driver installation file to system

chroot /mnt/sysimage

- ← Switch to the top(/) directory in system
- # sh /tmp/hptdd/RHEL-install-step2.sh
- ← Install NVMe controller driver

rm -rf /tmp/hptdd

← Delete the driver file in system

exit

← Exit the top(/) directory of the system

```
[anaconda root@localhost /]# cp -r /tmp/hptdd /mmt/sysimage/tmp/hptdd
[anaconda root@localhost /]# chroot /mmt/sysimage/
[anaconda root@localhost /]# sh /tmp/hptdd/rhel-install-step2.sh

Driver Installation

Updating 4.18.0-425.3.1.el8.x86_64...

Driver installation step 2 completed.

[anaconda root@localhost /]# rm -rf /tmp/hptdd/
[anaconda root@localhost /]# exit

exit

[anaconda root@localhost /]# _
```

- j. Press ALT+F6 to switch back to installation screen and finish the installation.
- k. If you want to boot from another kernel, please install the SSD7000 driver after entering the system.
- 1. Restart to enter the system, please connect to the internet:
- m. Download the appropriate driver from the Software Downloads web page.

Please execute the following command before installing the driver, **please connect to the internet:**

- Log in to your Redhat account password.
 # subscription-manager register --username xxx --password=xxx --auto-attach
- 2) Extract the driver package:

```
tar\ zxvf\ HighPoint\_NVMe\_G5\_Linux\_Src\_Src\_vx.xx.xx\_xx\_xx\_xx\_xx.tar.gz
```

Run the .bin file to install the driver package.

```
sh hptnvme g5 linux src vxx.x.x xx xx xx.bin or
```

./hptnvme g5 linux src vxx.x.x xx xx xx.bin

n. Follow the prompts to complete the driver installation.

```
SUCCESS: Driver hptnvme is installed successfully for kernel 4.18.0-425.3.1.el8.x86_64. Please restart the system for the driver to take effect. If you want to uninstall the driver from the computer, please run hptuninhptnvme to uninstall the driver files. [root@localhost home]#
```

o. After RHEL has been installed, you can reconnect the system to the network/internet and update the system as needed.

3 Monitoring the Driver

Once the driver is running, you can monitor it through the Linux proc file system support. There is a special file under /proc/scsi/hptnvme /. Through this file you can view driver status and send control commands to the driver.

Note

The file name is the SCSI host number allocated by OS. If you have no other SCSI cards installed, it will be 0. In the following sections, we will use x to represent this number.

Using the following command to show driver status:

cat /proc/scsi/ hptnvme /x

This command will show the driver version number, physical device list and logical device list.

4 Installing RAID Management Software

HighPoint's RAID Management Software can be used to check the status of the SSDs and RAID arrays hosted by the NVMe controller. Installation of the management software is optional but recommended.

Please refer to HighPoint RAID Management Software documentation for more information.

5 Troubleshooting

If you do not install the system or update the kernel according to the installation manual, the system will crash and you will not be able to enter. Please follow the steps below.

a. Choose "Red Hat Enterprise Linux (4.18.0-425.3.1.el8.x86_64)8.7." and enter the system.

```
Red Hat Enterprise Linux (4.18.0–425.3.1.el8.x86_64) 8.7 (Ootpa)
Red Hat Enterprise Linux (0–rescue–d876da976b4a496794c5e34297c432ed) 8.7▶
System setup
```

- b. Install Linux Opensource driver.
- c. Download the appropriate driver from the Software Downloads web page.
- d. Run the .bin file to install the driver package.

```
sh hptnvme_g5_linux_src_vxx.x.x_xx_xx_xx.bin or
```

./hptnvme g5 linux src vxx.x.x xx xx xx.bin

e. Follow the prompts to complete the driver installation.

```
SUCCESS: Driver hptnvme is installed successfully for kernel 4.18.0-425.3.1.el8.x86_64. Please restart the system for the driver to take effect. If you want to uninstall the driver from the computer, please run hptuninhptnvme to uninstall the driver files. [root@localhost home]#
```

f. After the installation is complete, you can perform system update operations.

6 Rebuilding Driver Module for System Update

When the system updates the kernel packages, the driver module hptnvme.ko should be built and installed manually before reboot.

Please refer to the README file distributed with NVMe controller opensource package on how to build and install the driver module.

7 Appendix A

Support command: help/info/quit/exit/create/delete.

• Create Command

Syntax

Create Array Type (RAID0/RAID1/RAID10) Member Disk list (1/1,1/2|*) Capacity (100|*)

Examples

```
<<< create RAID0
```

<<< create RAID0 *

<<< create RAID0 * *

Create RAID0 array with all disks and with maximum capacity.

<< create RAID1 1/1, 1/3 10

Create RAID1 array with disk 1/1 and 1/3 and with 10GB capacity.

<<< create RAID10

<<< create RAID10 *

<<< create RAID10 * *

Create RAID10 array with all disks and with maximum capacity.

• Delete Command

Syntax

delete {array ID}

Examples

<<< delete 1

Delete the first array from Logical device list.

<<< delete 2

Delete the second array from Logical device list.

• Info Command

Syntax

info

Display physical device list and logical list

Exit Command

Syntax

Q/q/quit/exit

Quit the application

Help Command

Syntax

H/h/help

This is help message.