




R9504A

Quad-Port 25GbE Network Adapter



Quick Installation Guide

V1.00

System Requirements

PC Requirements

- System with a free PCIe x16 slot

Operating System


- Windows 11
- Windows 10
- Windows server2016/ server2019/ server2022
- RHEL 9.1/ 8.7
- SLES15PS4
- Ubuntu 22.04/ 20.04
- Debian 11
- FreeBSD 13/ 12.3
- ESXi8.0

R9504A Kit Content

- 1x R9504A Network Adapter
- 1x Quick Installation Guide
- 1x Low Profile Bracket

R9504A Hardware

Front View



Hardware Installation

The following steps show how to install the adapter into your system.

1. Use a wired ESD wrist strap that is properly grounded.
2. Unpack and remove the R9504A and check it for damage. If it appears damaged, please get in touch with HighPoint Technical Support.
3. Shut down the system.
4. Press down gently but firmly to seat the R9504A correctly into the available slot.
5. Power on the system.

Resources

Various guides are available for the R9504A Network Adapter.

For Documentation and more information about this product, please visit the following website:

<https://www.highpoint-tech.com/enterprise-nic/rocket-9504a>

Certified Accessories:

<https://www.highpoint-tech.com/nvme-accessories>

Customer Support

If you encounter any problems while utilizing the R9504A or have questions about this or any other HighPoint Technologies, Inc. product, please contact our Customer Support Department.

Web Support:

<https://www.highpoint-tech.com/support-and-services>

HighPoint Technologies, Inc. websites:

<https://www.highpoint-tech.com>