RAID Controller/ Enclosure Port Guide

V1.26- June 10, 2026

Content

SSD7000

SSD7101A-1	
SSD7104	
SSD7105	
SSD7204	
SSD7140	

SSD7140A	
SSD7540	
SSD7749M	
SSD7749M2	
SSD7749E	
SSD7505	

SSD7202



SSD7502



SSD7120



8643-8643-060

8643-8639-50

SSD7180



	8643-8639-50 
SSD7184	 
SSD7580A	 

SSD7580B	 
SSD7580C	 

SSD6780A	

SSD6000

SSD6540/6540M	 
SSD6780A	 
SSD6444A	 

RocketAIC

RocketAIC **7505HW Series**	
RocketAIC **7505HM Series**	
RocketAIC **7540HW Series**	
RocketAIC **7540HM Series**	
RocketAIC **7749EW Series**	
RocketAIC **7749EM Series**	

RocketAIC **7749MW Series**	
RocketAIC **7749MM Series**	
RocketAIC **7749M2W Series**	
RocketAIC **7502HW Series**	
RocketAIC **7140AW Series**	
RocketAIC **7140AM Series**	
RocketAIC **7105HW Series**	

RocketAIC **7105HM Series**	
RocketAIC **7202HM Series**	
RocketAIC **7204HM Series**	
RocketAIC **7608AW Series**	

Rocket 1000

Rocket 1628A	
Rocket 1608A	
Rocket 1528D	

Rocket 1749E	
Rocket 1604A	
Rocket 1624A	
Rocket 1604L	**Two M.2 SSDs**  **Three M.2 SSDs** 

	Four M.2 SSDs 
Rocket 1624L	

Rocket 7000

Rocket 7628A	
Rocket 7628U	
Rocket 7608A	

Rocket 7528D	
Rocket 7528U	
Rocket 7604A	
Rocket 7638D	

Rocket 7624A	
Rocket 7634D	

RocketStor 6000

RS6542AW	 
RA6542AWW-S491T5-12	 
RS6541AW	 

SSD6200

SSD6202	
SSD6204	
SSD6202A	
SSD6204A	

RR600

RR620	
RR620L	
RR642L	
RR640L	
Cable	

RR800

RR840A



RR840C



Cable connection details，E.g RR840C

RR3700

RR3740A	
RR3740C	
RR3720A	
RR3720C	
RR3742A	
Cable connection details，E.g RR3740C	


PORT1
SFF-8643
P1
P2
P3
P4
Channel 1 in WEBGUI
Channel 2 in WEBGUI
Channel 3 in WEBGUI
Channel 4 in WEBGUI
PORT2
SFF-8643
Channel 5 in WEBGUI
Channel 6 in WEBGUI
Channel 7 in WEBGUI
Channel 8 in WEBGUI
PORT3
SFF-8643
Channel 9 in WEBGUI
Channel 10 in WEBGUI
Channel 11 in WEBGUI
Channel 12 in WEBGUI
PORT4
SFF-8643
Channel 13 in WEBGUI
Channel 14 in WEBGUI
Channel 15 in WEBGUI
Channel 16 in WEBGUI

RR2800

RR2840A	
RR2840C	
Cable connection details，E.g RR2840C	

	

RR4500

RR4520SGL	

RR4522SGL	 Channel 1/2/3/4 in WEBGUI Channel 5/6/7/8 in WEBGUI PORT1 PORT2 Port1 Port2 port2 port1 channel 8 channel 7 channel 6 channel 5 channel 4 channel 3 channel 2 channel 1

RR2700

RR2720A	
RR2721	
RR2722A	

RR2711	 
RR2782	
RR2744	

RS643xTS

RS6438TS

RS6434TS

Connect to port **a** of RR3742A(Channel1/2/3/4), Connect to port **b** of RR3742A(Channel5/6/7/8):



Rocket

Rocket 710	
Rocket 720	
Rocket 710L	
Rocket 720L	

Thunderbolt™ 3

RS6628A	
RS6674T	
RS6614V	
RS6618V	

USB

RS6124V	
RS6114V	

Adapter

MCIO-PCIEX16-G5	

Chassis

RocketStor **4243AS**