




Rocket 1628A (R1628A)

8x NVMe Port to PCIe 5.0 x16 NVMe Switch Adapter



Quick Installation Guide

V1.00

System Requirements

PC Requirements


- System with a free PCIe5.0 (or 3.0 or 4.0) x16 slot
- All the Operating Systems with Native NVMe Driver

R1628A Kit Content


- 1x R1628A NVMe Switch Adapter
- 1x Quick Installation Guide
- 1x Low Profile Bracket

R1628A Hardware

Front View



LED View



Note: Please refer to the detailed description of LED colors and their status in the R1628A NVMe Switch Adapter User Guide on the official website.

Hardware Installation

The R1628A provides four MCIO connectors. These connectors accept a variety of HighPoint Certified Cable Accessories (see the Accessories section towards the end of this guide for more information). The following steps explain how to connect U.2 NVMe SSDs directly to the R1628A using HighPoint CIO8-8639-110 cable.


1. Use a wired ESD wrist strap that is properly grounded.
2. Unpack and remove the R1628A and check it for damage. If it appears damaged, please get in touch with HighPoint Technical Support.
3. Shut down the system and disconnect the AC power cord.

4. Align the R1628A to one of the motherboard's available slots. Press down gently but firmly to seat the R1628A correctly in the slot.




Note: Replace the full-height bracket on the R1628A with the optional low-profile bracket if required by your system.

5. Connect the SFF-8639 connector of the CIO8-8639-110 cable to the NVMe SSD, and connect the 15-pin SATA power connector to the power supply.



6. Connect the MCIO connector of the CIO8-8639-110 cable to the R1628A.



7. Connect the remaining NVMe SSDs to the R1628A as described above.
8. Turn on the power to the system.

Note: Please ensure the cables are securely connected to the R1628A's device ports and the NVMe SSDs or backplanes. Loose connections can lead to various problems, including instability, slower-than-expected performance, and dropped disks.



Optional Certified Cable Accessories

CIO8-8639-110



MCIO (x8) Host to U.2 SFF-8639 Device cable with a 15-pin SATA power connector. Each cable supports two NVMe SSDs.

Length: 1M (100cm)/39.37"

<p>CIO8-CIO8-110</p> 	<p>MCIO (x8) Host to MCIO (x8) Device cable. Each cable can host up to two NVMe SSDs.</p> <p>Length: 1M (100cm)/39.37"</p>
<p>8654-CIO8-110</p> 	<p>MCIO Host to SFF-8654 Device cable. Each cable can host up to two NVMe SSDs.</p> <p>Length: 1M (100cm)/39.37"</p>

Resources

A variety of guides and FAQs are available for the R1628A NVMe Switch Adapter.

For Documentation and more information about this product, please visit the following website:

<https://www.highpoint-tech.com/nvme-aic/r1628a>

Certified Accessories:

<https://www.highpoint-tech.com/nvme-accessories>

FAQ & Troubleshooting:

[FAQ - HighPoint Technologies, Inc. \(helpjuice.com\)](https://www.highpoint-tech.com/helpjuice.com)

Customer Support

If you encounter any problems while utilizing the R1628A or have questions about this or any other HighPoint Technologies, Inc. product, please contact our Customer Support Department.

Web Support:

<https://www.highpoint-tech.com/support-and-services>

HighPoint Technologies, Inc. websites:

<https://www.highpoint-tech.com>